


# KL91-0100

## INSTALLATION INSTRUCTIONS

UNIT IS SUPPLIED WITH TWO OPTIONAL ADAPTERS  
TO ACCOMMODATE THREE DIFFERENT SPOUT THREADS

1. REMOVE ANY EXISTING AERATOR FROM FAUCET BODY
2. INSTALL ADAPTER & WASHER ONTO FAUCET IF NECESSARY
3. INSTALL HANDWASH FAUCET WITH WASHER  
(*HAND TIGHTEN ONLY*)



**COMPONENT  
HARDWARE®**

1890 Swarthmore Avenue  
PO Box 2020  
Lakewood, NJ 08701  
Tel. 800-526-3694  
Fax. 732-364-8110  
www.componenthardware.com

#K91-X100 12/13